

STYLE NO. 6000XL

Robark™

**ROBOT AM BAND RADIO
INSTRUCTION MANUAL**

 **STAR
COMMAND™**
SERIES
by Caprice®

STYLE NO. 6000XL

Robark (MARQUE DÉPOSÉE)

**RADIO-ROBOT AM
INSTRUCTIONS MANUELLES**

SÉRIE
 **STAR
COMMAND™** (MARQUE DÉPOSÉE)
par Caprice®

INTRODUCTION

Your STAR COMMAND RADIO is manufactured with a powerful solid state circuit receiving the standard AM broadcast band, 525-1620KHz. Its conceptive design not only features a flashing LED as a space alert light, but its distinctive design makes it the perfect practical item for every child's room. Any child can follow the manual to operate the set easily.

PREPARATION FOR USE

This radio operates from a standard 9 volt radio battery, 006P or equivalent.

1. Remove the battery cover.
2. Snap in a standard 9V battery.
3. Replace the battery cover.

Note: Never leave weak or dead battery in your unit. It may leak, damaging the unit. If you are not going to use your unit for a period of time, remove the battery.

OPERATION

1. Turn the volume control knob to switch on the set.
2. Select your desired station by turning the tuning knob.
3. Adjust the volume control to your preferred listening level.
4. To switch off the radio, turn the volume control knob to the opposite direction until you hear a 'click'.

CARE AND MAINTENANCE

With proper care, the radio will provide endless hours of enjoyment. Clean the cabinet with a soft cloth. Never use strong cleaning agents as they could damage the finish. Avoid storing the radio in excessively hot, cold or damp places. Do not attempt to disassemble the cabinet. For service, always refer to a qualified serviceman.

INTRODUCTION

Votre RADIO MAITRE STELLAIRE est fabriquée avec un système de circuit transistorisé puissant pour recevoir les émissions radiodiffusées standards AM, 525-1620 Khz. Son modèle a été conçu non seulement avec les caractéristiques d'une LED clignotante pour la lumière d'alerte spatiale, mais avec une forme distinctive qui en fait le jouet parfait pour toute chambre d'enfant. N'importe quel enfant peut suivre le manuel pour faire fonctionner facilement l'appareil.

PREPARATION POUR SON EMPLOI

Cette radio fonctionne par une pile standard de 9 volt, 006P ou équivalente.

1. Enlevez le couvercle du compartiment à pile.
2. Engagez une pile standard de 9V.
3. Remplacez le couvercle du compartiment à pile.

Remarque: Ne laissez jamais une pile faible ou épuisée dans votre radio. Elle pourrait suinter, endommageant l'appareil. Si vous n'envisagez pas d'utiliser votre appareil pendant une longue période, retirez la pile.

FONCTIONNEMENT

1. Tournez le bouton du contrôle de volume pour mettre l'appareil en marche.
2. Sélectionnez votre station désirée en tournant le bouton de syntonisation.
3. Ajustez le contrôle de volume à votre niveau d'écoute préféré.
4. Pour arrêter la radio, tournez le bouton du contrôle de volume dans la direction opposée jusqu'à ce que vous entendiez un 'clic'.

SOIN EN ENTRETIEN

Si vous en prenez soin correctement, la radio vous donnera de nombreuses heures de divertissement. Nettoyez le coffret avec un chiffon doux. N'employez jamais de produits de nettoyage décapant car ils pourraient endommager la finition de l'appareil. Evitez d'entreposer la radio dans des endroits excessivement chauds, froids ou humides. N'essayez pas de démonter le coffret. Pour toutes réparations, adressez-vous toujours à un réparateur qualifié.