


# STARROID-I

Radio Control Talking Robot.




## How To Place Batteries and Antennas

Place 3 'D' cell batteries and 2 '9-volt' radio batteries as shown in illustration. Be sure that  $\oplus$  and  $\ominus$  ends are properly aligned.



Attach antennas to robot and control unit by screwing as shown in illustration.



## How To Operate

Turn switch on body of robot to 'ON'.  
Place robot on floor or level surface.  
Insert message or objects in spring action hands.  
Turn control unit to 'ON'.  
Hold control unit with two antennas pointing straight up.  
Press button on control unit for forward, right or left turn action.  
Control unit has 25 feet (open air) control range.

### To Walk

1. Turn switch on control unit to 'ON'.
  2. Place robot on floor or level surface.
  3. If desired, insert message or objects in spring action hands.
  4. Turn switch on robot to 'ON'.
  5. Hold control unit with two antennas pointing straight up.
  6. Press desired button on control unit for forward, right or left turn action.
- Note: Staroid-1

## To Talk

1. Turn switch on body of robot to 'ON'.
2. Place robot with antenna pointing straight up.
3. Turn switch on control unit to 'ON'.
4. Hold control unit with two antennas pointing straight up.
5. Press 'Alarm' and 'Talk' buttons to signal a communication.
6. Press in 'Talk' button and speak into control unit speaker.
7. Adjust 'Volume Control' to desired level.

Note: For combination fun, send Staroid-1 on a walk. Press 'Alarm' and 'Talk' buttons to signal. Then send your message through Staroid-1 by pressing 'Talk' button.

## For Two-Way Communications

1. One caller uses control unit, one caller uses robot.
2. Follow directions above. First caller signals a communication by pressing 'Alarm' and 'Talk' buttons, and then presses in 'Talk' button and speaks into speaker.

## Special Instructions

1. Do not play with Staroid-1 on rough or wet surface.
2. Do not force to hold the robot while operating.
3. Be sure that when Staroid-1 is not played, turn off switches on robot and control unit. If Staroid-1 will not be played for an extended period of time, remove batteries to prevent damage from leakage.

